

## Wall Clock Safe

Welcome!

Thanks for choosing the Wall Clock Safe. This manual will provide you with directions for the effective operation of the Wall Clock Safe. Please review the manual carefully before operating this product and store in a safe place for future reference.

### Features:

1. Displays time, hours, minutes, seconds.
2. 12 hour time mode.

### Batteries:

Requires 1 "AA" (DC 1.5V) Battery (Not Included).

When the seconds needle stops moving, or slows down, please replace battery. Replace batteries by turning the clock towards the back and insert 1 New "AA" (DC 1.5V) battery in the battery compartment, making sure to align the polarity of the batteries as indicated on the inside of the battery compartment. It is recommended that Alkaline Batteries be used for better performance.

### Battery Warnings:

Batteries Contain Mercury. Do Not put in Trash. Recycle or Manage as Hazardous Waste.

Do Not Mix Old and New Batteries. Do Not Mix Alkaline, Standard (Carbon-Zinc), or Rechargeable (Nickel-Cadmium) Batteries.

Replace Batteries as a simultaneous set.

Insert Batteries as indicated with the proper polarity alignment.

### Use and Operation:

#### Setting Time

Turn the dial on the quartz clock module, near the battery compartment clockwise or anti-clockwise to set the hours need and the minute needle to the desired time, and let go. If the battery is there the clock will start running.

### CAUTION:

Do not put the unit in the sun, or expose it to sunlight. When the clock stops or the second hand needle slows down, replace the 1 "AA" (DC 1.5V) battery

Never immerse the unit in water or any other liquid or fluid as this will damage the unit. Do not wash the unit or clean under a running tap.

Take care and do not put the unit near heat, fire, or in direct sunlight.