


Instant Mesh Guard

Keep your doors open and the bugs out!

Easy Installation Instructions



1. Place the Instant Mesh Guard flat on the floor with magnets aligned to the center.
2. Check each magnet to ensure they are lined up and attract each other.
3. Peel the adhesive backing off of the hook and strips and apply to the Instant Mesh Guard. Please see the diagram for placement instructions.
4. Take Side A and peel off hook and loop strip P1 and apply to corner of door frame. Please press hard for a secure fit. Repeat for hook and loop strips P2 through P6.
5. Take Side B and peel off hook and loop strip P7 and apply to opposite corner of door frame. Please press hard for a secure fit. Repeat for hook and loop strips P8 through P12.

Installation Information

For wooden frames, you may also use the tacks provided. Using the tacks will leave puncture holes.

For plastic frames, please only use the double-faced adhesive tape. Do not use the tacks.

Product may not function properly if isn't installed correctly.

Cleaning and Storage

Wipe the mesh with a clean, damp, lukewarm cloth. For hard to remove dirt, you can spot clean with a small amount of mild soap and a cloth. Allow the mesh to air-dry. Do not use any abrasive cleaners on the Instant Mesh Guard.

Do not put in the dryer. Do not dry clean.

Safety Information

Please keep the tacks away from children.

Maintain a proper distance from heat sources such as ovens, radiators, water heaters and stoves.

Because of possible electromagnetic interference, people with implanted medical devices (e.g. pace makers) should consult their doctor before using the Instant Mesh Guard.



WARNING:

There is a danger of suffocation with the storage bag and packing material. Keep away from children. Instant Mesh Guard is not a barrier for children and pets. Do not use Instant Mesh Guard if you do not want small children or pets to get out.