

Installation Instructions

1. Locate reverse lights and select a route for the power wire that will connect to the power source
2. Clean the inside surface of the bumper so that the sensor strip will mount properly

NOTE: Some vehicles might require you to remove the bumper to be able to access the inside part and to install the sensor.
3. Place the end of the magnetic strip with the connector near the area where the power wire will come through
4. Remove the tape backing off and unroll the magnetic sensor strip along side the inside of the bumper.
5. Press the sensor strip firmly against the inside of the bumper
6. Connect the magnetic sensor strip to the control unit
7. Connect the power cable and buzzer to the control unit
8. Route the RED and BLACK wires towards the reverse lights you selected for power
9. Place the control unit in the trunk and secure on the inside panel using the double sided tape.
10. Mount and place the buzzer towards the front of the vehicle to maximize its performance

